

Installation Kit

Prior to leaving for a logger installation, ensure that the installation kit contains the following:



le or 2-w

(single)



(2-way)

- ☐ NMEA 2000 drop cables (1-m or 0.5-m, of the correct connector either 0183, 2000 type N or 2000 type R)



- ☐ Tape measure
- ☐ Outdoor double-sided Velcro
- ☐ Pens
- ☐ Blank MOU (if not already filled out - see Templates for examples)
- ☐ Offset worksheets (if not already filled out - see Templates for examples)
- ☐ Metadata forms (if not already filled out - see Templates for examples)
- ☐ Logger + backup (of the correct connector - either 0183, 2000 type N, or 2000 type R)
- ☐ MicroSD card with Config file already loaded (linked YDVR here, example in Templates)

Optional and backup supplies:

- ☐ NMEA 2000 elbow connector



☐ NMEA 2000 terminator cap



☐ NMEA 2000 power isolator



☐ Thru bolts



☐ Screw drivers

☐ Pliers

☐ Zip ties

☐ Scissors

☐ Electrical tape

☐ Duct tape

☐ Epoxy

- ☐ Desiccant packets
- ☐ Cleaning solvent
- ☐ Cleaning wipes/rags

Revision #5

Created 2026-01-14 21:49:57 UTC by Sophie Chernoch

Updated 2026-01-22 01:45:48 UTC by Sophie Chernoch