

Installation Kit

Prior to leaving for a logger installation, ensure that the installation kit contains the following:



le or 2-w.

(single)



(2-way)

- NMEA 2000 drop cables (1-m or 0.5-m, of the correct connector either 0183, 2000 type N or 2000 type R)



- Tape measure
- Outdoor double-sided Velcro
- Pens
- Blank MOU (if not already filled out - see Templates for examples)
- Offset worksheets (if not already filled out - see Templates for examples)
- Metadata forms (if not already filled out - see Templates for examples)
- Logger + backup (of the correct connector - either 0183, 2000 type N, or 2000 type R)
- MicroSD card with Config file already loaded (linked YDVR here, example in Templates)

Optional and backup supplies:

- NMEA 2000 elbow connector



NMEA 2000 terminator cap



NMEA 2000 power isolator



Thru bolts



Screw drivers

Pliers

Zip ties

Scissors

Electrical tape

Duct tape

Epoxy

- Desiccant packets
- Cleaning solvent
- Cleaning wipes/rags

Revision #5

Created 2026-01-14 21:49:57 UTC by Sophie Chernoch

Updated 2026-01-22 01:45:48 UTC by Sophie Chernoch